




20 TON AIR HYDRAULIC BOTTLE JACK

OPERATING INSTRUCTIONS MANUAL

MODEL : AHBJ20000





OPERATING INSTRUCTIONS MANUAL

20 TON AIR HYDRAULIC

BOTTLE JACK

MODEL : AHBJ20000

NO	STOCK CODE	DESCRIPTION	QTY	NO	STOCK CODE	DESCRIPTION	QTY
1		Base	1	29		Snap ring "C"	1
2		Ball 1/4"	1	30		Packing	1
3		Seal	1	31		Top nut	1
4		Release valve	1	32		"O" ring	1
5		"O" ring	1	33		Spring	2
6		Cylinder	1	34		Spring plate	1
7		Washer	1	35		Nut	1
8		Check valve kit	1	36		"O" ring	1
9		Seal	1	37		"O" ring	1
10		Cap washer	1	38		Packing	1
11		Pump cylinder	1	39		Throttle	1
12		"O" ring	1	40		Spring	1
13		Handle	2	41		Valve body	1
14		Cup seal	1	42		Hose connector	1
15		Cack up ring	1	43		Spring	1
16		Pump plunger	1	44		Air filter	1
17		Handle sleeve	1	45		Lever	1
18		Pin	1	46		Lock level	1
19		Cotter pin	2	47		Level pin	1
20		Pin	1	48		Hose connector	1
21		Packing	1	49		Hose band	2
22		Reservoir	1	50		Air hose	1
23		Filler plug	1	51		Pump elbow	1
24		Extension screw	1	52		Air motor	1
25		Ram	1	53		Spring washer	2
26		Bushing	1	54		Nut	2
27		Cup seal	1	55		Eye bolt	2
28		Cap washer	1		TRS20TAHBJ		