




1250LB ENGINE STAND

OPERATING INSTRUCTIONS MANUAL

MODEL : ES1250LB





1250LB ENGINE STAND

OPERATING INSTRUCTIONS MANUAL

MODEL : ES1250LB

ITEM	STOCK CODE	DESCRIPTION	QTY	ITEM	STOCK CODE	DESCRIPTION	QTY
1		MAIN POST	1	15		ROTATION HANDLE	1
2		FRONT HEAM	2	16		NAME PLATE	1
3		SIDE HEAM	1	17		WHELL,REAR 3-1/8"	2
4		BOLT M12x90	6	18	TR1250C	CASTER,3-1/2"	2
5		LOCK WASHER,12	12	19		BOLT M8x20	8
6		HEX NUT M12	8	20		HEX NUT,M8	8
7		BOLT M12x30	2	21		LOCK WASHER,8	8
8		HEAD,MOUNTING PLATE	1	22		BOLT,M10x60	2
9		LOCK PIN	1	23		WASHER,FLAT 10	2
10	TR125010	MOUNTING ARMS	4	24		LOCK WASHER,10	2
11		BOLT M12x50	4	25		HEX NUT,M10	2
12		WASHER FLAT 12	12	26		STEEL TUBE	2
13		HEX NUT M12	4		DE1TRM1250ES	MOUNTING	
14		TOOL TRAY	1		DHTRMP1250ES	MOUNTING PLATE	