




# 1.5 TON TRANSMISSION JACK OPERATING INSTRUCTIONS MANUAL

## MODEL : TJE1500





# 1.5 TON TRANSMISSION JACK OPERATING INSTRUCTIONS MANUAL

## MODEL : TJE1500

PART	STOCK CODE	DESCRIPTION	QTY
1		SADDLE PLATE	1
2		WEDGE	4
3		TILT ADJUSTMENT KNOB	2
4		LIFT ARM	1
5		HANDLE	1
6		RELEASE VALVE	1
7		CHASSIS	1
8		CASTER	4
9		CHAIN	2
	TRS15TTJ	SEALS	